

DUOMESH

AMAZON

STAINLESS STEEL LINED BASKET FILTERS

DUOMESH lined basket filters have been designed to be used in standard bag filter housings and to provide cost effective filtration for a wide range of applications. The baskets are manufactured from 316L stainless steel mesh so can be cleaned and reused time and time again. **DUOMESH** basket filters are available in a range of removal ratings from 50 –2000µm so can be used for fine, medium or coarse clarification or as a prefilter to finer filters downstream. They are available as single, double or triple length baskets and in different diameters.

Product Features

- Robust construction in 316L stainless steel
- Available in single or triple layer mesh providing removal ratings from 50 to 2000µm
- Can be supplied as single, double or triple length baskets
- Range of collar sizes available
- Offered with a handle to aid removal from housing
- Consistent and reliable performance under a wide range of process conditions

Filter Housings

Amazon Filters manufacture a comprehensive range of filter housings for the **DUOMESH** baskets. These can be manufactured from a range of metals and in different sizes so can be supplied to suit all flow rates. Please consult our Sales Office for further details on these ranges.



DUOMESH FEATURES AND BENEFITS

- Available in a range of removal ratings so suitable for a wide range of filtration applications
- 316L construction offers wide chemical and process compatibility
- Offered with a handle to aid removal from housing

DUOMESH

TECHNICAL DATA

Maximum Operating Conditions

Temperature: 200°C

Recommended Maximum Differential Pressure: 5 bar g

Materials of Construction

316L Stainless Steel

50 and 100µm versions use triple layer media. (870µm upstream and downstream)

Dimensional Data

Bag Size	Length (mm)	Ring Diameter (mm)	Compatible Housings
Single MINI (P3)	200	108	81
Double MINI (P4)	355	108	81
Single Amazon	420	140	82/83/87
Double Amazon	810	140	82/83/87
Triple Amazon	1220	140	82/83/87
Single Universal (P1)	420	178	84/85/86/88/89
Double Universal (P2)	810	178	84/85/86/88/89
Triple Universal	1220	178	84/85/86/88/89

INDUSTRIES AND APPLICATIONS

Food and Beverage	•	General process water
Pharmaceutical	•	Particulate removal from creams, lotions and gels, solids recovery
Fine Chemicals	•	Polymers, acids, bases, solvents
Water Treatment	•	Raw water filtration
Coatings	•	Paints, inks, resins and varnishes

AMAZON FILTERS LTD.

ALBANY PARK ESTATE, FRIMLEY ROAD,
CAMBERLEY, SURREY, GU16 7PG
ENGLAND

Tel: +44 (0) 1276 670 600

Fax: +44 (0) 1276 670 101

Email: sales@amazonfilters.co.uk

Web: www.amazonfilters.com



Certificate No. FM39584

Distributed by: