


63 SERIES

Multi Stack Filter Housing



The **63 Series Contour** Multi cartridge housing is designed to accommodate 3, 5, 7, 10 or 15 stacks of filters up to 40" long. The centre positioned, split shell opening style is equipped with a Cast Vee clamp as standard for liquid pressures ranging from 7 - 10 bar g.

Equipped with the inverted dished end, this free standing housing with split shell design is the ideal choice when using Single Open End plug in style cartridges. The simple to lift off lightweight dome allows full and easy access to the cartridges for rapid changeouts. With the ability to accept both standard Double Open End and Single Open End cartridges, this housing will suit most applications where finer levels of filtration are required. Bolted closures are an option available for all models.

The **63 Series** will accept the full range of Amazon and industry standard cartridges with nominal lengths of 20, 30 and 40".

Note: 7 round housings only accept 66.5mm maximum diameter cartridges.

Product Features

- Split body design allows easy access to cartridges for filter changeout
- Free standing, easy to install design style
- Vee clamp closures use unique 'W' style seal for reliable leak free operation
- High quality cast Vee band clamps for safety and security
- Cast compression nut with integral PTFE washer for easy, hand tight cartridge sealing
- Wide range of connection sizes and types available
- PED and ATEX Compliant
- DWI Approved product

Accessories

Pressure Gauge and Vent Valve Kit



Pressure Gauge and Auto Vent Valve Kit



Ball Valve and Nipple



Features and Benefits

- Large selection of housing sizes available so suitable for a wide range of processes
- Integral vent, clean and dirty drains to aid efficient filter changeout
- Each housing is etched with a unique serial number for full traceability
- 'W' style seal for reliable leak free operation
- Cast compression nut with integral PTFE washer for easy, hand tight cartridge sealing
- Wide range of connection sizes and types, cartridge lengths and materials of construction
- Universal cup allows the use of plug in (Code 3 and Code 8) or DOE cartridge styles in the same housing
- DWI Approved product

Product Range

Amazon Filters design and manufacture an extensive range of liquid filtration systems, providing one of the widest selections of filtration vessels, depth filters and pleated cartridges available today, ensuring excellent process and filter compatibility.

As one of Europe's leading manufacturers of filtration systems, Amazon Filters offers solutions to meet all filtration requirements. Amazons' filters are manufactured in clean room conditions and all products come with detailed Product Validation Guides and Technical Support documentation.



AMAZON

63 Series Technical Data

Maximum Operating Conditions

	6303	6305	6307	6310	6315
Liquid: Vee clamp:	10 bar g	10 bar g	10 bar g	10 bar g	7 bar g
Bolted closure:	FV/10 bar g	FV/10 bar g	FV/10 bar g	FV/10 bar g	FV/10 bar g
Gas: Vee clamp:	7.5 bar g	4.5 bar g	4.5 bar g	2 bar g	1.5 bar g
Bolted closure:	FV/7.5 bar g	FV/7.5 bar g	FV/7.5 bar g	FV/7.5 bar g	FV/7.5 bar g
Temperature Range:	-10°C / 150°C				

Materials of Construction

Body:	316L St. Steel
Closure:	Vee Clamp - 304 St.Steel
	Screw Clamps - Zinc plated carbon steel (Optional Stainless Steel)
Vessel Finish:	Electropolished

Connections

	6103-05	6310	6315
Inlet/Outlet:	2" BSPM	3" BSPM	4" BSPM
Vent	¼" BSPM	¼" BSPM	½" BSPM
Drain:	½" BSPM	½" BSPM	1" BSPM

PED* / PESR Status:** Compliant with PED 2014/68/EU & PESR 2016 No.1105

Fluid Groups: Liquids Group 2
Gas Group 2



Markings: CE

ATEX: Compliant with 2014/34/EU and
Explosive Atmosphere Regulations 2016
II 2G Ex h IIC T150 Gb
II 2D Ex h IIC T150 Db

* Pressure Equipment Directive

** Pressure Equipment (Safety) Regulations No. 1105

Technical drawings for each individual housing showing dimensions, volume, weights, maximum temperatures and design pressures available on request.



Ordering Guide

6305	2	0	A	N	20	A	1	E	E
No of Stacks	Cartridge Length	Cartridge End Cap Style	Closure Style	Mounting	Connection	Connection Type	Materials	Finish	Seal
6303 - 3 6305 - 5 6307 - 7*1 6310 - 10 6315 - 15	2 - 20" (6303 & 6305 only) 3 - 30" 4 - 40"	0 - Code 0 7 - Code 7 8 - Code 8 A - Code A U - Universal	A - Cast Vee Clamp E - Dome cover with screw clamps T - Dome cover with St.St. screw clamps	N - None A - Bolt Down Plate	3 - 7 Stack 20 - 2" 30 - 3" (6305 + 6307 only) 10 - 15 Stack 30 - 3" 40 - 4"	A - BSPM C - EN1092-1 Flange PN16 H - ANSI Flange 150# G - Table E Flange S - DIN2633 Flange K - Stub Pipe M - DIN11851 Male N - RJTM P - SMS M (Swedish) R - IDFM L - BS4825-3 Tri Clamp U - NPTM (2" only)	1 - 316 St.St. (L grade)	E - Electropolished	E - Ethylene Propylene F - FEP / Silicone (screw clamp only) S - Silicone (screw clamp only) V - Viton

Example: 630520AN20A1EE = 63 Series, 5 x 20" DOE cartridge, Cast vee clamp closure, No mounting, 2" BSPM connections. 316L St.Steel construction with EPDM gaskets, electropolished all over.

*1 - Accepts cartridges of maximum OD 66.5mm

Note: Not all options are available on every housing, please refer to Sales Office.

AMAZON FILTERS LTD.

Albany Park Estate, Camberley, Surrey, GU16 7PG, ENGLAND

Tel. +44 (0) 1276 670 600 Email. sales@amazonfilters.co.uk Web: www.amazonfilters.com

Contour is a trademark of Amazon Filters Ltd.

AMAZON FILTERS LTD. reserve the right to change specification without prior notice, as part of their continuous product development programme.

63 - Issue 06